



LAPD @ PC4 ODH SYSTEM TEST PROCEDURE

OVERVIEW: This Procedure covers testing of the ODH monitor system after installation and for future tests that may be required. This test will check that the heads when sensing an oxygen deficiency will place the system in alarm, the appropriate horns and strobe lights will be activated and a FIRUS message will be sent to the communications center.

PREPARATION: The test should be conducted when the minimum amount of personnel are working in the area to reduce disruptive effect of blaring sirens and flashing strobes.

A team of two people equipped with radios and a test procedure would be adequate to conduct an efficient test. The test coordinator keeps the master record of the test.

Test Coordinator

Record data

Tester #1 Disconnect each ODH Head and Monitor zone horn and strobe

PROCEDURE: LAPD at PC4 BUILDING HIBAY

| Call the communicat | ions center (x3414) and notify the operator that a test of the |
|-----------------------------|---|
| LAPD at PC4 ODH system | will be conducted and that you will need a printout of the |
| FIRUS alarms they will rece | ive during the test. |
| Call the Main Contro | ive during the test. l Room(MCR) (x3721) and notify the operator that a test of |
| the LAPD at PC4 ODH syste | em will be conducted and they will receive FIRUS alarms |
| during the test. | · |
| Set the HIBAY ODH | ventilation fan to auto mode. This fan should be off. |
| | |
| FIRUS TAG NAMES: | 05. PC4-ODH |
| | |

05. PC4-ODH-TRBL

Check the team is in place and ready.

| TEST HEAD # 1 |
|---|
| Horn/Strobe activated in HIBAY |
| Horn/Strobe activated in Entryway |
| HIBAY Ventilation Fan Start and Run |
| iFIX HMI ODH picture displays ODH Alarm |
| FIRUS system received message TIME 17: 3 (|
| ODH chassis display is correct 18.85 % TRIPPO @ |
| 2 00 00 |
| A BLANCE REELINED IT LA |
| Horn/Strobe activated in HIBAY |
| Horn/Strobe activated in Entryway |
| HIBAY Ventilation Fan Start and Run |
| 1FIX HMI ODH picture displays ODH Alarm |
| JIKUS System received message TIME 1973 20 |
| ODH chassis display is correct 18.9 % TRIPPED @ |
| 2006 |
| • |
| TEST ODH TROUBLE |
| Disconnect DC supply Fuse in ODH Control Box |
| ODH chassis display is correct a 24.6 % I Come OIS PERY |
| FIRUS system received message. TIME: 67:30 |
| iFIX HMI ODH picture displays ODH Trouble |
| |
| AFTER TEST IS COMPLETED: |
| |
| Check that the ODH system is react and |
| Check that the ODH system is reset and ready to return to normal operation. |
| Call the communications center (x2414) and xis |
| LAPD at PC4 ODH system has been completed and to respond to any further alarms. |
| Pick up a copy of the FIRUS alarm printout from the communications center and record the times in the master test |
| the times in the master test. |
| |
| Call the Main Control Room(MCR) (x3721) and notify the operator the test of the LAPD at PC4 ODH system has been completed and to any the control Room (MCR) (x3721) and notify the operator the test of the |
| LAPD at PC4 ODH system has been completed and to respond to any further alarms. |
| e despond to any further alarms. |
| Generate a copy of the master test for any logs and the safety review panel. |
| CLIDEDAY A COLOR OF THE COLOR PARCE. |
| SUPERVISOR OF TEST / MOTHY J. MARTIN DATE: 10-26-12 |
| SUPERVISOR OF TEST TIMOTHY J. MARTIN DATE: 10-26-12 |
| |

TEST FORM---Dan Markley 7/22/2011

FIRUS PRINTAUT

| 10/26/2012 7:25 Proton Center Pit | 10/26/2012 7:25 Proton Center Pit | 10/26/2012 7:26 Proton Center Dit | 10/26/2012 7:26 Proton Center Pit | 10/26/2012 7:29 Protop Center Bit | 10/26/2012 7:29 Proton Center Bit | 10/26/2012 7:30 Proton Center Pit | 10/26/2012 7:31 Proton Center Dit | בי/ בי/ ביבי / ישב ווסוסון בני / ביי בי / בי |
|-----------------------------------|-----------------------------------|-----------------------------------|-----------------------------------|-----------------------------------|-----------------------------------|-----------------------------------|-----------------------------------|--|
| IN-ALARM | NORMAL | IN-ALARM | NORMAL | IN-ALARM | NORMAL | IN-ALARM | NORMAL | ! |
| Utility | Utility | Utility | Utility | Trouble | Trouble | Trouble | Trouble | |
| 05.PC4-ODH | 05.PC4-0DH | 05.PC4-0DH | 05.PC4-0DH | 05.PC4-ODH TRBL | 05.PC4-ODH TRBL | 05.PC4-ODH TRBL | 05.PC4-ODH TRBL | |

High High High High High High